

Occupancy & Vacancy Sensors

VACANCY SENSORS

- **California Title 24 Compliant**
- Manual ON
- Automatic OFF after time delay expires and manual OFF option
- Adjustable time delay from 15 seconds to 30 minutes
- Adjustable sensitivity settings
- Passive Infrared Technology
- 2 year warranty
- Standard decorative wall plate included
- Compatible with **MAGNETIC** and **ELECTRONIC BALLAST**
- Neutral Wire Required



Cat. No.	Description	Color (Cat. No. - Color Code)			Std. Pkg.
		White	Ivory	Almond	
T24VSD-S	Passive Infrared Vacancy Sensor, 180°, 650 Sq. Ft. Coverage RATING: Incandescent: 800W @120VAC Fluorescent: 800VA @120VAC 1600VA @ 277VAC Motor: 1/4HP@ 120VAC	T24VSD-S-W	T24VSD-S-I	T24VSD-S-A	10
T24VS-S	Passive Infrared Vacancy Sensor, 150°, 450 Sq. Ft. Coverage RATING: Incandescent: 500W @120VAC Fluorescent: 500VA @120VAC Motor: 1/8HP@ 120VAC	T24VS-S-W	T24VS-S-I	-	10



OCCUPANCY SENSORS

- **California Title 24 Compliant**
- Turn lights ON/OFF automatically
- With manual ON/OFF pushbutton
- Adjustable time delay from 15 seconds to 30 minutes
- 5 year warranty
- Standard decorative wall plate included
- Compatible with **MAGNETIC** and **ELECTRONIC BALLAST**
- **NEUTRAL** wire required



Cat. No.	Description	Color (Cat. No. - Color Code)			Std. Pkg.
		White	Ivory	Almond	
OSD-S	Passive Infrared Occupancy Sensor, 180°, 650 Sq. Ft. Coverage RATING: Incandescent: 800W @120VAC Fluorescent: 800VA @120VAC Motor: 1/4HP@ 120VAC	OSD-S-W	OSD-S-I	OSD-S-A	10



Cat. No.	Description	Color (Cat. No. - Color Code)			Std. Pkg.
		White	Ivory	Almond	
OSD-S-2W	Passive Infrared Occupancy Sensor, 180°, 1200 Sq. Ft. Coverage RATING: Incandescent: 800W @120VAC Fluorescent: 800VA @120VAC Motor: 1/4HP@ 120VAC	OSD-S-2W-W	OSD-S-2W-I	-	10



- **California Title 24 Compliant**
- Turn lights ON/OFF automatically
- With manual ON/OFF pushbutton
- Built-in VAC selection side button switch
- Adjustable time delay from 15 seconds to 30 minutes
- "Walk-through" sensing mode increases energy savings by turning light OFF shortly after momentary occupancy
- Self adaptive feature automatically adjust time delay based on occupants behavior patterns
- 5 year warranty
- Standard decorative wall plate included
- Compatible with **MAGNETIC** and **ELECTRONIC BALLAST**
- **NO NEUTRAL** wire required
- **GROUND WIRE** connection required.



NOTE: Vacancy and Occupancy Sensors should be initially left ON for 4-5 minutes for first time to function properly.